

Opel 2000 old style

manufactured by RSF in BC with serial number starting with WH

Note:

-Original back panel replaced by 2 cement panels FR-11.1.P (left) & FR-11.2.P (right)

-Side panels were held by a vertical metal bracket that will need to be removed and replaced with 2-refractory clips FR-98.11.03.P

-Original unit did not have cement panels on the floor, it can be retro fitted with FR-11.14.P (left side) & FR-11.15.P(right side) & FR-11.18.P (round plug)

